

# Topper Attachment

LK4054



## FEATURES

Service shops to remove or install a fiberglass or aluminum pickup box topper. This attachment attaches to the lift in seconds by loosening four star knobs, sliding the four Topper Attachment components into the designated area of the lift and tightening the star knobs. Once the topper is unbolted and ready to be removed or installed, the technician will lift each corner of the topper up a couple of inches and place something soft that won't scratch the paint between the bed rail and the topper to create a couple inch gap between the bed rail and topper. The technician can then center the lift into the box, slide the four connecting points of the Topper Attachment outward to connect to the topper. Once this is done the topper can be raised, removed or installed from the pickup and moved around the shop at ease. This is a one person, one tool operation.



[www.network1solutions.com](http://www.network1solutions.com)

