

Email: sales@autel.com Web: www.autel.com

ASSEMBLY INSTRUCTION

MaxiSys ADAS (Pattern Board)


Thank you for purchasing this Autel diagnostic tool. This tool, manufactured to a high standard, if used according to the instructions and properly maintained, will give you years of trouble-free performance.



WARNING:


- Serious or fatal crushing injuries can occur from frame tip-over. To prevent the calibration frame from tipping over it must be secured to the ground during the assembly.
- Improper assembly of the calibration frame may result in permanent damage to the frame and may render it inoperable and/or unsafe

Parts List











Assemble the pattern board



Step 1: Align the screw holes on two handles with those on the back of the pattern board. Place the flat washers (M5) over the screw holes and then insert bolts (M5x16) and tighten using the hex L-wrench (4mm).



Step 2: Align the two screw holes on the bubble level with those on the back of pattern board. Insert bolts (M5x10) and tighten using the hex L-wrench (4mm).